

⚠ WARNING! ⚠

Hazard: Improper use or failure to follow instructions can result in explosive failure causing serious eye or other injury. For safe use of this product you must read and follow all instructions. Do not leave a pressurized sprayer in the hot sun. Heat can cause pressure build-up. Do not store or leave solution in tank after use. Always wear goggles, gloves, long sleeve shirt, long pants and full foot protection when spraying. Never use any tool to remove pump if there is pressure in sprayer. Never stand with face or body over top of tank when pumping or loosening pump to prevent ejecting pump assembly and/or solution from striking and injuring you. Never pressurize sprayer by any means other than the original pump. Do not attempt to modify or repair this product except with original manufacturer's parts. **Never spray flammable materials or heat, pressure, or gas producing chemicals. Always read and follow manufacturer's instructions before use with this sprayer as some chemicals may be hazardous when used with this sprayer.** Sk-1113-1

WARNING: Handling the brass parts of this product will expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm. *Wash hands after handling.*

Congratulations!

You have just purchased a quality Chapin product. Register Your Sprayer Online @ www.chapinmfg.com
Questions? Do Not Return To Store. Call us @ 1-800-950-4458 or www.chapinmfg.com

¡Felicitaciones!

Usted acaba de adquirir un producto de calidad Chapin. Registre su pulverizador en línea en www.chapinmfg.com
¿Preguntas? No regrese a la tienda; llámenos al 1-800-950-4458 o visite www.chapinmfg.com

Félicitations!

Vous avez acheté un produit de qualité Chapin. Enregistrez dès que possible votre pulvérisateur en ligne à l'adresse suivante: www.chapinmfg.com
Questions ? Ne retournez pas au magasin. Appelez-nous 1-800-950-4458 ou visitez le www.chapinmfg.com



Parts, Piezas, Pièces

	6-7749 Extension wand (poly) Vara de extensión Rallonge		6-7756 Extension wand (brass) Vara de extensión Lance de rallonge
	6-2001 Hose Kit: 2 nuts, 2 barbs and hose Juego de manguera: 2 tuercas, 2 lengüetas y manguera. Nécessaire de tuyau: Deux écrous, deux artilillons et tuyau		6-8156 Relief Valve Válvula de descarga de presión Soupape de décompression
	010842 Tool Holder Soporte para la herramienta Porte-outils		6-2000 Shut-off Handle Mango de cierre Poignée du robinet
	301120-4 Fan Nozzle (brass tip) Boquilla Buse		301272-1 Nozzle (brass tip) Boquilla Buse
	6-4566 Four Position Nozzle Boquilla de 4 posiciones Buse à 4 positions		6-6003 Nozzle Boquilla Buse
	6-4645 Relief Valve Válvula de descarga de presión Soupape de décompression		6-3337 Straps Tirantes Sangles
	6-5385 Spray Shield Pantalla de pulverización Bouclier de pulvérisation		6-5364 Measure Cup Taza para medir Tasse à mesurer
	3-4843 Fan Nozzle Pack Paquete de boquilla a chorro Ensamble de buse à jet éventail		

Note: Your particular sprayer may not include all parts pictured above.
Nota: Es posible que este pulverizador no incluya todas las partes que se ilustran arriba.
Remarque: Votre pulvérisateur particulier pourrait ne pas inclure toutes les pièces illustrées plus haut.


Repair Parts Kit Gaskets and Seals (not included),
 Juego de piezas de reparación, empaquetaduras y juntas (no incluido)
 Kit de pièces de réparation, joints et garniture d'étanchéité (non inclus)

6-1925

⚠ WARNING! ⚠

To prevent hose from blowing off, hose must cover both barbs on the outlet tube adapter and touch flange (Fig. 1B) before hose nut is securely tightened (Fig. 1C).


1. Hose to Tank



Discharge/ Tool Holder Assembly


- Insure the tool holder is assembled to the tank adapter before mounting the discharge assembly (Fig.1A). The Tool Holder snaps into the groove of the tank adapter. Figure 1D shows how the shield and cup are mounted (Not all models are provided with tool holder, spray shield and measuring cup).
- Insert the outlet tube portion of the discharge assembly into the tank adapter (Fig. 1A).
- Firmly insert the outlet tube portion into the tank adapter (Fig. 1B) leaving no gap between the tank adapter and outlet tube adapter. Firmly tighten the retaining nut to the tank adapter (Fig. 1C).

2. Nozzle / Extension Wand



Attach nozzle to shut-off handle or extension wand per Fig. 2A-2D depending on the style of extension wand included with sprayer.

Deck Sprayers Only (Fig. 2D-2G)



Insert nozzle into cap (2E).


Attach cap to shut-off handle or extension wand (Fig. 2F-2G).



3. Filter


The filter helps prevent clogging while spraying. It is located on the end of the outlet tube inside your sprayer tank. To clean filter, remove the discharge assembly from the tank (Fig.1A). Make sure the filter is positioned at the bottom of the tank as pictured (Fig. 3A).

Note: Filters are not supplied with deck sprayers.



4. Shield Attachment to Wand

Snap shield onto wand as shown. Using the spray shield will help protect your plants etc. from over spray. (Not all models are provided with spray shield).




5. Pre-Use Check

- 1) **Do:** Check tightness of hose nut to be sure hose is securely attached to the tank outlet.
- 2) **Do:** Inspect hose for deterioration, cracks, softness, or brittleness. If any of these conditions are found, replace hose before using. Replace with original manufacturer's parts only.
- 3) **Do:** Remove pump (see Filling, Pressurizing and Spraying Instructions), inspect interior and exterior of tank for signs of deterioration of body and bottom. Any sign of deterioration indicates possible tank weakening and could result in explosive bursting under pressure. If any of these signs are found, discard tank immediately and replace. Do not attempt to patch leaks, etc., as this could result in serious injury.
- 4) **Do:** Follow Filling, Pressurizing and Spraying Instructions, except use water only (Pump plunger 10-20 strokes and inspect for leaks).
- 5) **Do:** Direct shut-off away from you and open to make sure discharge is not clogged.
- 6) **Do:** If unit passes this test, release pressure (see Pressure Releasing Instructions), empty tank, and proceed with Filling, Pressurizing and Spraying Instructions.

6. Filling

- 1) **Do:** Turn pump handle counterclockwise and remove pump
- 2) **Do:** Prepare spray solution following all directions and safety warnings on chemical label.
- 3) **Do:** Fill tank to no more than the proper gallon marker. Do NOT: overfill to accommodate pump.
- 4) **Do:** Check pump to make sure that no grass or dirt is stuck to barrel. Replace pump in tank and tighten securely.

7. Pressurizing and Spraying



Do: Turn handle clockwise to tighten. Push handle down, turn 1/4 turn counterclockwise to release.

Do: Pump until you feel resistance.

Do: Push handle, down, turn 1/4 turn clockwise to lock. Begin spraying. Re-pump sprayer as required to maintain spray force.

Do: Turn end of nozzle to adjust spray pattern.

8. To Release Pressure

Sprayers with no pressure release valve

Do: With pump facing away, turn locked handle counterclockwise until air begins to escape. Stop turning handle when you hear air escaping. **Do:** Point pump away until all air has escaped.

Sprayers with pressure release/relief valve

Fig. 8A: Lift and hold the cap OR, turn the valve slowly counterclockwise until air is completely exhausted.

Fig. 8B: Pull up stem until air is completely exhausted.

Do: Point valve away from you when releasing pressure.



9. Care, Storage and Maintenance

- 1) **Do:** Rinse tank thoroughly with water only, empty, refill with water. Follow Filling, Pressurizing and Spraying Instructions, except pump unit only 8-10 strokes.
- 2) **Do:** Open shut-off and allow water to run through discharge assembly.
- 3) **Do:** Release pressure (Follow Pressure Release Instructions), remove pump and empty sprayer.
- 4) **Do:** Store sprayer tank upside down, with pump removed, in a warm dry location.
- 5) **Do:** Periodically oil pump by dropping 10-12 drops of light oil down pump rod through opening in cover.

10. Fatigue-Free Spraying


For constant spraying, push down on shut-off handle and move grey locking mechanism away from you. To release, squeeze handle and move the grey locking mechanism back towards you. (Not all models are provided with this feature).



11. Troubleshooting - Tank pressurizes but does not spray.

WARNING: Release pressure in tank before troubleshooting.

Clean shut-off (Fig. 11A- 11D)



Pull handle straight up.

Insert notches from underside of handle into plunger grooves and turn counterclockwise.

Remove plunger and diaphragm. Clean plunger, diaphragm and body. Flip diaphragm and replace.

Tighten plunger clockwise until flush to top of shut-off body. Do not over-tighten or unit may not spray. Slide forks under plunger, push handle down until it snaps into place.

Clean Nozzle Assembly (Fig. 11E) -Remove nozzle cap. Clean and re-assemble.

